ClientMate VMWare ESXi 5.X

1、ClientMate VMWare ESXi 5.0 Installation

1. Save file of ClientMate ESXi5.tar.gz under directory of   /vmfs/volumes/datastore1

2. Unzip ClientMate ESXi5.tar.gz to create directory ClientMate

3.Rename ClientMate directory to ClientMate_install

4. Enter to ClientMate _install directory

5. Change install.clientmate authority by entering command chmod 755 ./install.clientmate

6.Execute ClientMate - ./install.clientmate

7. PC quering if install under directory of /vmfs/volumes/datastore1/clientmate? Yes or NO

8. Press ENTER to execute


```
/vmfs/volumes/5134ad07-749b6a29-5dc0-000c2952c4cf/clientmate_install # ./install.clientmate
ClientMate for VMWare

Would you like to install ClientMate for VMWare to the directory /vmfs/volumes/datastore1/clientmate? (Y)es, (N)o. [y]
ClientMate for VMWare Will be installed to /vmfs/volumes/datastore1/clientmate.
Press ENTER to continue ...

Create /vmfs/volumes/datastore1/clientmate directory...

Moving files from /vmfs/volumes/datastore1/clientmate_install to /vmfs/volumes/datastore1/clientmate .......
Creating help subdirectory...
OK.

Adding entries in /etc/rc.local ....

Backup /etc/rc.local to /etc/rc.local.old.clientmate
Adding startup command to /etc/rc.local startup file.


OK.
Press ENTER to continue...
```

2：Enter ClientMate configuration page，ClientMate installation completed。

```
(SNMP ClientMate for VMWare) UPS Configuration Utility, Ver. 3.5
   Copyright(C) 2010 MegaTec System Technologies, Inc.2013-03-04, 15:16 Mon.
+-----------------------------------------------------------------------+
|       [d] System Shutdown Delay Time When AC Power Failed:  5.0 Min.   |
|       [b] System Shutdown Delay Time When Battery Low    :  1.0 Min.   |
|       [u] UPS Turn Off Delay Time                       :  3.0 Min.   |
|                                                                       |
|       [o] Community Name    :  public                                 |
|       [p] Ip Address        :  127.0.0.1                              |
|       [n] Shutdown Count Down Display: ON                             |
|                                                                       |
|       [a] Turn off UPS after System Shutdown: YES                     |
|                                                                       |
|                                                                       |
|                                                                       |
|                                                                       |
|                                                                       |
|                                                                       |
|       [s] Save Configuration.                                         |
|       [q] Quit.                                                       |
+-----------------------------------------------------------------------+
        Press the letters in brackets to select items.
        Press [+], [-], or [i], [m] to change values.
        Press [r] to redraw screen.
```